

PLASKOLITE

Sanitizing Acrylic and Polycarbonate Sheet

When disinfecting or sanitizing OPTIX Acrylic and TUFFAK Polycarbonate proper procedures should be taken. To minimize the risk of damage, use only compatible household cleaners and correct cleaning procedures as outlined below. For more details please contact the Plaskolite Technical Service Group at 800.628.5084 with any questions.

Disinfectants/Sanitizers for Plaskolite Products

Product Brand	Manufacturer	Products	Compatibility**
TUFFAK	sBioMed, LLC	Steriplex SD	Compatible
TUFFAK	Safetec of America	Safetec Surface Wipes	Compatible
TUFFAK	CONTEC Healthcare	Perodox RTU	Compatible
TUFFAK	CONTEC Healthcare	Prostat Sterile Wipes PS-911EB	Compatible
OPTIX	Generic	Hydrogen Peroxide - pharmacy grade	Compatible
OPTIX	Generic	Bleach - household grade	Compatible
OPTIX	Generic	Isopropyl Alcohol -diluted with water to 30% strength	Compatible
TUFFAK	Procter & Gamble	Clorox Health Care Bleach Germicidal Cleaner	Not Compatible
TUFFAK	Unimeg Corp	Accel TB	Not Compatible
TUFFAK	Procter & Gamble	Clorox Broad Spectrum Quaternary Disinfectant Cleaner	Not Compatible
TUFFAK	Zep Inc	ZEP 40	Not Compatible
TUFFAK	Zep Inc	ZEP Spirit II	Not Compatible
TUFFAK	PDI Inc	PDI Super Sani-Cloth	Not Compatible
TUFFAK	Reckitt Benckiser	Lysol Disinfection Spray Brand III Original	Not Compatible
TUFFAK	Fiberlock Technologies Inc	Shockwave Disinfectant	Not Compatible
TUFFAK	CONTEC Healthcare	Preempt RTU Multi-surface disinfectant cleaner	Not Compatible
TUFFAK	Procter & Gamble	Clorox Regular Bleach 100%	Not Compatible
TUFFAK	Procter & Gamble	Clorox Regular Bleach 50%	Not Compatible
TUFFAK	Procter & Gamble	Clorox Regular Bleach 10%	Not Compatible
TUFFAK	Procter & Gamble	Clorox Regular Bleach 1%	Not Compatible
OPTIX	Generic	Ethyl Alcohol - pharmacy grade	Not Compatible

SPECIAL NOTES:

Polycarbonate products were tested on uncoated sheets. Do not use unapproved cleaners or disinfectants on sheet products. Generally speaking, Hydrogen peroxide and Isopropyl alcohol based sanitizers work best as disinfectants on polycarbonate. Disinfectants containing Hydroxides, Dimethyl benzyl or Ethyl ammonium chloride, Ethylenediamines and Hypochlorite will crack the polycarbonate sheets.

**Because manufacturers sometimes change their formulas without notification compatibility in perpetuity can not be presumed.

The manner in which you use our products, technical assistance and information (whether verbal, written or by way of production evaluations), including any suggested formulations and recommendations, are beyond our control. Therefore, it is imperative that you test our products, technical assistance and information to determine to your own satisfaction whether our products, technical assistance and information are suitable for your intended uses and applications. This includes testing to determine suitability from a technical as well as health, safety, and environmental standpoint. Such testing has not necessarily been done by us. All information and technical assistance is given without warranty or guarantee and is subject to change without notice. It is expressly understood and agreed that you assume and hereby expressly release us from all liability, in tort, contract or otherwise, incurred in connection with the use of our products, technical assistance, and information. Nothing herein shall be construed as a recommendation to use any product in conflict with any claim of any patent relative to any material or its use. No license is implied or in fact granted under the claims of any patent.

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use are beyond our control. We recommend that the prospective user determines the suitability of our materials and suggestions before adopting them on a commercial scale.

PLASKOLITE

400 W. Nationwide Blvd. STE 400
Columbus, Ohio 43216
800-848-9124 • Fax: 877-538-0754
Email: plaskolite@plaskolite.com
www.plaskolite.com